



EXPOSE

LAYER FILM & ART

- STENCIL FILM WITH TEXTURED SIDE UP
 - ARTWORK SO YOU CAN READ IT
 - CLEAR COVER SHEET & RUB DOWN TO SEAL
-

35 SECONDS

WITH 18" BAR FOR 10" X 12" FILM

1 MIN 40 SEC

WITH 23" EXTENDER BAR FOR 12" X 18" FILM

WASH & DRY FILM

- WASH STENCIL UNTIL IMAGE IS REVEALED
 - DRY ON A FLAT SURFACE
 - STENCIL SHOULD BE COMPLETELY DRY
-

2-3 MINUTES

WITH 18" BAR FOR 10" X 12" FILM

4-6 MINUTES

WITH 23" EXTENDER BAR FOR 12" X 18" FILM

POST EXPOSE